


## This is a sample of a typical wall section. Your plan may differ from the assembly shown. DRAW YOUR OWN SECTION REPRESENTING YOUR PROJECT.



I:\FORMS\Handouts\2007 Code\Wall Section Summer 2007.doc

DISCHARGE TO DAYLIGHT OR SUMP. INSTALL WEEPERS

THROUGH UPPER ½ OF FOOTING TO ALLOW FLOW TO INTERIOR DRAIN. (SUMP OR DAYLIGHT, NOT SEWER)